

PT100 Climate Shelter Assembly/Adjustment Process

1) First step

Firmly secure the lower hex thread (34 mm) with a spanner or wrench



2) Second step

Using a second wrench, tighten the top hex thread 3/4" (25 mm).

